



## Product Technical File

### Something Different Wholesale LTD

UK Business Address - Enterprise Park, Upper Fforest Way, Llansamlet,  
Swansea SA6 8PJ

EU Business Address - Posthoornstraat 11, 3011WD, Rotterdam, NETHER-  
LANDS

Telephone - +44 (0)1792 940288 Email [customer@somethingdifferent-  
wholesale.co.uk](mailto:customer@somethingdifferent-wholesale.co.uk)

Item Code:AN\_98426  
Product Name:Lantern Multi-Purpose Ceramic Burner  
Barcode:5056131175945





### **Product Description**

Shaped like a traditional lantern, this ceramic burner brings warmth and elegance to any setting. This multi-purpose piece is suitable for use with fragrance oil diluted with water, incense cones, and bakhoor, making it perfect for creating a personalised home fragrance experience. Featuring a removable lid and intricate cut-out detailing, it's ideal for both everyday use and special occasions. Do not use more than one tealight and remove lid when in use. Never leave a lit candle unattended. Designed by Something Different Wholesale and part of the Arabian Nights collection of home fragrance gifts and home decor.

The product is produced in China

### **Product Dimensions:**

W 10.6cm x H 23.7cm x D 10.6cm

### **Product Weight:**

856.6g

### **Product Materials :**

Stoneware

### **Packaging Materials:**

Colour Cardboard Box

### **Tracability:**

1745230/06/202500677-25

### **Packaging Information:**

W 10.6cm x H 23.7cm x D 10.6cm

### **Packed Weight:**

896.5g



## Declaration of Conformity

Something Different Wholesale Ltd, Upper Fforest Way, Enterprise Park,  
Swansea, SA6 8PJ

Contact Person- Anthony David

Email – [customercare@somethingdifferentwholesale.co.uk](mailto:customercare@somethingdifferentwholesale.co.uk)

Phone Number – 01792 940288



Product Name: Lantern Multi-Purpose Ceramic Burner

ModelG-OB

Product Code: AN\_98426

We at Something Different Wholesale LTD recognise that the product mentioned in this document conforms to UK standards and regulations. This product upholds the UK specifications attached to it.

Authorising Name: Anthony David

Company Name: Something Different Wholesale LTD

Authorising Signature:

A handwritten signature in black ink, consisting of a stylized 'A' followed by a long horizontal line.

Date: 10.06.2025  
Review Date:10.06.2026

## EU Declaration of Conformity

Name- Something Different Wholesale Ltd  
Address- Something Different Wholesale Ltd, Posthoornstraat 11, 3011WD,  
Rotterdam, NETHERLANDS  
Contact person- Anthony David  
Email – EU@somethingdifferentwholesale.co.uk  
Phone Number – +441792 940288



Product Name: Lantern Multi-Purpose Ceramic Burner  
Model:G-OB  
Product Code:AN\_98426

We at Something Different Wholesale LTD recognise that the product mentioned in this document conforms to UK standards and regulations. This product upholds the UK specifications attached to it.

Authorising Name: Anthony David  
Company Name: Something Different Wholesale LTD  
Authorising Signature:

A handwritten signature in black ink, appearing to be 'Anthony David', written over a horizontal line.

Date: 10.04.2025  
Review Date:10.04.2026

**Product Label**

# Oil & Wax burner warning

## Burner without lid

**How to use:**


- Ensure the burner is placed on a flat, clutter free, and heat-resistant surface.
- Check that the area is open and has good air flow.
- Fill the dish with an appropriate amount of wax, do not overfill the dish. If using a fragrance oil, use 2 to 3 drops of oil diluted with water.
- Place one unscented tealight candle at the bottom of the burner and ensure the wick is standing.
- Light the candle with a long handled lighter.
- Check your burner periodically. Maintain an appropriate level of oil or wax in the dish and watch the burner for smoke. If your burner begins to smoke, extinguish the candle, clean your burner and start over with a new tealight.
- Extinguish the candle if you are going to be out of the room. Use a candle snuffer and do not blow out.
- Do not touch the oil, wax or holder until it has completely cooled.

**How to clean:**

- Allow burner to completely cool before cleaning.
- To remove wax, wait for wax to harden then carefully scoop out.
- Clean residue with warm, soapy water and dry.

**Warning**

- 1.Never put more wax or oil into your burner while the candle is still burning.
- 2.Extinguish the candle first to ensure your safety.
- 3.Do not overfill your burner. This may cause it to splash and catch on fire.
- 4.Do not place the burner in a location where it will be easily knocked over.
- 5.Keep away from flammable objects.
- 6.Never leave a burning candle unattended.
- 7.Keep your burner away from children and pets.
- 8.Keep your burner clean. Dispose of any unused wax or oil after you are finished using your burner.
- 9.Always read and follow the manufacturer's instructions on candles.
- 10.Do not allow hot wax or oil to come in contact with skin.



## Burner with lid

**How to use:**


- Ensure the burner is placed on a flat, clutter free, and heat-resistant surface.
- Check that the area is open and has good air flow.
- Remove the lid and fill the dish with an appropriate amount of wax, do not overfill the dish. If using a fragrance oil, use 2 to 3 drops of oil diluted with water.
- Place one unscented tealight candle at the bottom of the burner and ensure the wick is standing.
- Light the candle with a long handled lighter.
- Remove the lid while the candle is burning.
- Check your burner periodically. Maintain an appropriate level of oil or wax in the dish, and watch the burner for smoke. If your burner begins to smoke, extinguish the candle, clean your burner and start over with a new tealight.
- Extinguish the candle if you are going to be out of the room. Use a candle snuffer and do not blow out.
- Do not touch the oil, wax or holder until it has completely cooled.

**How to clean:**

- Allow burner to completely cool before cleaning.
- To remove wax, wait for wax to harden then carefully scoop out.
- Clean residue with warm, soapy water and dry.

**Warning:**

- 1.Keep lid off while candle is burning.
- 2.Never put more wax or oil into your burner while the candle is still burning.
- 3.Extinguish the candle first to ensure your safety.
- 4.Do not overfill your burner. This may cause it to splash and catch on fire.
- 5.Do not place the burner in a location where it will be easily knocked over.
- 6.Keep away from flammable objects.
- 7.Never leave a burning candle unattended.
- 8.Keep your burner away from children and pets.
- 9.Keep your burner clean. Dispose of any unused wax or oil after you are finished using your burner.
- 10.Always read and follow the manufacturer's instructions on candles. Do not allow hot wax or oil to come in contact with skin.



## Directions for Use

This product is designed for decorative purposes to create pleasing visual aesthetics for the customer as an addition to their desired interior surface. Whilst this product is compliant within GPSR regulations, it is imperative that the product is used appropriately to ensure customer safety. It is the customer's responsibility to source the correct protective measures for their intended surface. We at Something Different Wholesale take no responsibility for injury or product damages due to incorrect installation, usage or storage of decorative items.

This product is for decorative home fragrance product purposes and is not a toy. This item should be kept out of reach from children and pets as products may contain small parts. This information is readily available on the product packaging.

Home fragrance burners are supplied with guidance and instructions for use for product usage, care and maintenance.

Hazard	Who might be harmed	Existing measure to control risk	Risk level
Allergies	General Public	Testing in accordance with; REACH regulation (EC 1907/2006), Food Contact Materials: Regulation EC 1935/2004, the Directive 84/500/EC, amendment Directive 2005/31/EC	Low
Choking	Children	Not a toy, Keep out of the reach of children	Low
Fire caused by freestanding candles	General Public, property	Product is supplied with fire safety advice.	Medium
Toxicology (Hazard chemicals causing side effects such as skin irritation)	General Public	Product is tested within CLP Regulation (EC) No 1272/2008: Registration of Product and UFI codes applied to labelling	Low
Injury	General Public	Product is supplied with fire safety advice.	Medium

## OIL ONLY burner warning

## Oil & Wax burner warning

### Burner without lid

### Burner with lid

### Burner without lid

### Burner with lid

**How to use:**


- Ensure the burner is placed on a flat, clutter free, and heat resistant surface.
- Check that the area is open and has good air flow.
- Fill the dish with an appropriate amount of oil, do not overfill the dish. Use approximately 7 to 3 drops of oil diluted with water.
- Place one unscented tealight candle at the bottom of the burner and ensure the wick is standing.
- Light the candle with a long handled lighter.
- Check your burner periodically. Maintain an appropriate level of oil in the dish, and watch the burner for smoke. If your burner begins to smoke, extinguish the candle, clean your burner and start over with a new tealight.
- Extinguish the candle if you are going to be out of the room. Use a candle snuffer and do not blow out.
- Do not touch the oil or holder until it has completely cooled.

**How to clean:**

- Allow burner to completely cool before cleaning.
- Clean residue with warm, soapy water and dry.

**Warning:**

- 1 Never put more oil into your burner while the candle is still burning.
- 2 Extinguish the candle first to ensure your safety.
- 3 Do not overfill your burner. This may cause it to splash and catch on fire.
- 4 Do not place the burner in a location where it will be easily knocked over.
- 5 Keep away from flammable objects.
- 6 Never leave a burning candle unattended.
- 7 Keep your burner away from children and pets.
- 8 Keep your burner clean. Dispose of any unused oil after you are finished using your burner.
- 9 Always read and follow the manufacturer's instructions on candles.
- 10 Do not allow hot oil to come in contact with skin.



**How to use:**


- Ensure the burner is placed on a flat, clutter free, and heat resistant surface.
- Check that the area is open and has good air flow.
- Remove the lid and fill the dish with an appropriate amount of oil, do not overfill the dish. Use 7 to 3 drops of oil diluted with water.
- Place one unscented tealight candle at the bottom of the burner and ensure the wick is standing.
- Light the candle with a long handled lighter.
- Remove the lid while the candle is burning.
- Check your burner periodically. Maintain an appropriate level of oil in the dish, and watch the burner for smoke. If your burner begins to smoke, extinguish the candle, clean your burner and start over with a new tealight.
- Extinguish the candle if you are going to be out of the room. Use a candle snuffer and do not blow out.
- Do not touch the oil or holder until it has completely cooled.

**How to clean:**

- Allow burner to completely cool before cleaning.
- Clean residue with warm, soapy water and dry.

**Warning:**

- 1 Keep lid off while candle is burning.
- 2 Allow put more oil into your burner while the candle is still burning.
- 3 Extinguish the candle first to ensure your safety.
- 4 Do not overfill your burner. This may cause it to splash and catch on fire.
- 5 Do not place the burner in a location where it will be easily knocked over.
- 6 Keep away from flammable objects.
- 7 Keep your burner away from children and pets.
- 8 Never leave a burning candle unattended.
- 9 Keep your burner clean. Dispose of any unused oil after you are finished using your burner.
- 10 Always read and follow the manufacturer's instructions on candles.
- 11 Do not allow hot oil to come in contact with skin.



**How to use:**


- Ensure the burner is placed on a flat, clutter free, and heat resistant surface.
- Check that the area is open and has good air flow.
- Fill the dish with an appropriate amount of wax, do not overfill the dish. If using a fragrance oil, use 2 to 3 drops of oil diluted with water.
- Place one unscented tealight candle at the bottom of the burner and ensure the wick is standing.
- Light the candle with a long handled lighter.
- Check your burner periodically. Maintain an appropriate level of oil or wax in the dish and watch the burner for smoke. If your burner begins to smoke, extinguish the candle, clean your burner and start over with a new tealight.
- Extinguish the candle if you are going to be out of the room. Use a candle snuffer and do not blow out.
- Do not touch the oil, wax or holder until it has completely cooled.

**How to clean:**

- Allow burner to completely cool before cleaning.
- To remove wax, wait for wax to harden then carefully scoop out.
- Clean residue with warm, soapy water and dry.

**Warning:**

- 1 Never put more wax or oil into your burner while the candle is still burning.
- 2 Do not overfill your burner. This may cause it to splash and catch on fire.
- 3 Do not place the burner in a location where it will be easily knocked over.
- 4 Keep away from flammable objects.
- 5 Never leave a burning candle unattended.
- 6 Keep your burner away from children and pets.
- 7 Keep your burner clean. Dispose of any unused wax or oil after you are finished using your burner.
- 8 Always read and follow the manufacturer's instructions on candles.
- 9 Do not allow hot wax or oil to come in contact with skin.



**How to use:**


- Ensure the burner is placed on a flat, clutter free, and heat resistant surface.
- Check that the area is open and has good air flow.
- Remove the lid and fill the dish with an appropriate amount of wax, do not overfill the dish. If using a fragrance oil, use 2 to 3 drops of oil diluted with water.
- Place one unscented tealight candle at the bottom of the burner and ensure the wick is standing.
- Light the candle with a long handled lighter.
- Remove the lid while the candle is burning.
- Check your burner periodically. Maintain an appropriate level of oil or wax in the dish and watch the burner for smoke. If your burner begins to smoke, extinguish the candle, clean your burner and start over with a new tealight.
- Extinguish the candle if you are going to be out of the room. Use a candle snuffer and do not blow out.
- Do not touch the oil, wax or holder until it has completely cooled.

**How to clean:**

- Allow burner to completely cool before cleaning.
- To remove wax, wait for wax to harden then carefully scoop out.
- Clean residue with warm, soapy water and dry.

**Warning:**

- 1 Keep lid off while candle is burning.
- 2 Never put more wax or oil into your burner while the candle is still burning.
- 3 Extinguish the candle first to ensure your safety.
- 4 Do not overfill your burner. This may cause it to splash and catch on fire.
- 5 Do not place the burner in a location where it will be easily knocked over.
- 6 Keep away from flammable objects.
- 7 Never leave a burning candle unattended.
- 8 Keep your burner away from children and pets.
- 9 Keep your burner clean. Dispose of any unused wax or oil after you are finished using your burner.
- 10 Always read and follow the manufacturer's instructions on candles. Do not allow hot wax or oil to come in contact with skin.





## Prism: Product Risk Assessment Methodology

Risk assessment background and summary of outcomes			
Assessor name:	Stacey Gannon	Organisation:	Something Different Wholesale LTD
Date of initial assessment:	21 March 2025	Assessment reviewed by:	
Date of last update:		Assessment review date:	
Product brand:		Product category:	Decorative articles
Product name/model:		Product subcategory:	
Other identifiers (such as batch reference):		Name of business that placed the product on the market:	<i>Something Different Wholesale LTD</i>
Applicable product safety legislation and standards:		Have images been captured of the product?:	Yes
Who is the product aimed at?:	General Public	Number of hazards identified:	3
Could unintended or non-users be at risk?	Yes	Can the product be presumed to present a serious risk without a quantified risk assessment?:	No
Single product item risk level:	Low risk	Has the risk outcome been revised to reflect there being multiple hazards?:	No, the hazard creating the greatest risk sufficiently reflects the overall product risk
Estimated number of product items in use:		Overall level of risk for product:	Low risk
Sensitivity analysis outcome:	Sensitivity analysis not performed	Uncertainty level:	Low uncertainty
Factors related to the nature of the risk: outcome:	There are no factors other than the risk level to take account of in relation to risk management decisions	Risk tolerability outcome:	Risk is tolerable









**Internal Test Report**

**Something Different Wholesale Ltd, Upper Fforest Way, Enterprise Park, Swansea, SA6 8PJ**  
**EU RP: Something Different Wholesale Ltd, Utrechtseweg 341, 3818 EL Amersfoort, Netherlands**

Testing date: 30/10/2025

Time Beginning: 10.00

Time concluded: 14.00

Product: AN\_98426

Product Name Lantern Multi-Purpose Ceramic Burner  
G-OB



<b>BS EN 15493 -Candles Specification for Fire Safety</b>		<b>Pass</b>
<b>CCPSA candles regulation (SOR/2016-165) section 1</b>		<b>Pass</b>
<b>BS EN 15494 -Candle Product Safety Label</b>		<b>Pass</b>
<b>EN 17885 - Candle Accessory Fire Safety</b>		<b>Pass</b>
<b>Wax Pool Temperature</b>		<b>Pass</b>
<b>Surface Temperrature</b>		<b>Pass</b>

We at Something Different Wholesale LTD recognise that the product mentioned in this document upholds the specifications attached to it.

Authorising Name: Anthony David

Company Name: Something Different Wholesale LTD

Authorising Signature:

**Date: 01/07/2025**

**Revision: 01/07/2026**

